

MAZDA RECOMMENDED MAINTENANCE PROGRAM

Revised: 15.05.2010

MAZDA2

MILEAGE	10K	15K	20K	25K	30K	35K	40K	45K	50K	55K	60K	65K	70K	75K	80K	85K	90K	95K	100K	105K	110K	115K	120K					
LABOUR / MATERIALS																												
ENGINE OIL	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R				
OIL FILTER	R		R		R		R		R		R		R		R		R		R		R		R	R				
SPARK PLUGS							R								R									R				
AIR FILTER	C/C		C/C		C/C		C/C		C/C		R		C/C		C/C		C/C		C/C		C/C		C/C	R				
FUEL FILTER							R								R									R				
ENGINE TUNING																												
ENGINE COOLANT	I		I		I		I/R		I		I		I		I/R		I		I		I		I	I				
DRIVE BELT	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A				
ENGINE IDLE SPEED	I		I		I		I		I		I		I		I		I		I		I		I	I				
COOLING SYSTEM	I		I		I		I		I		I		I		I		I		I		I		I	I				
ENGINE VALVE CLEARANCE																								I/A				
EVAPORATIVE SYSTEM (IF INSTALL)	I		I		I		I		I		I		I		I		I		I		I		I	I				
BRAKES																												
BRAKE FLUID	I	I	I	I	I	I	R	I	I	I	I	I	I	I	R	I	I	I	I	I	I	I	I	R				
PARKING BRAKE	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I				
DISC BRAKE	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I				
BRAKE DRUM	I		I		I		I		I		I		I		I		I		I		I		I	I				
BRAKE LINES HOSES & CONNECTION	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I				
POWER BRAKE UNIT (BRAKE BOOSTER) & HOSE	I		I		I		I		I		I		I		I		I		I		I		I	I				
TYRES																												
ROTATION inc. BALANCING	P		P		P		P		P		P		P		P		P		P		P		P	P				
PRESSURE check inc. spare tyre	C/F		C/F		C/F		C/F		C/F		C/F		C/F		C/F		C/F		C/F		C/F		C/F	C/F				
STEERING ALIGNMENT																												
STEERING LINKAGES & OPERATIONS	I		I		I		I		I		I		I		I		I		I		I		I	I				
STEERING LINES, HOSES, CONNECTION & FLUID	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I				
CHASSIS																												
FRT & RR SUSPENSION, BALL JOINTS							I								I									I				
FUEL LINES & HOSES	I		I		I		I		I		I		I		I		I		I		I		I	I				
BOLT/NUTS ON CHASSIS & BODY	T		T		T		T		T		T		T		T		T		T		T		T	T				
DRIVE SHAFT BOOT							I								I									I				
EXHAUST SYSTEM HEAT SHIELD							I								I									I				
AUTO TRANS LEVEL	I		I		I		I		I		I		I		I		I		I		I		I	I				
AUTO TRANS FLUID									R												R							
ELECTRICAL																												
BATTERY CONDITION	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I				
ELECTRICAL SYSTEM & LIGHTING	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I				
LEGEND																												
R REPLACE	C/F CHECK/FILL UP				I INSPECTION				I/A INSPECT/ADJUST				C/C CHECK/CLEAN				L LUBRICATE				T TIGHTEN				P PERFORM			
FREE CAR WASH & VACUUM																												