

MAZDA RECOMMENDED MAINTENANCE PROGRAM

Revised : 15.05.2010

RX-8 (Manual)

MILEAGE	10K	15K	20K	25K	30K	35K	40K	45K	50K	55K	60K	65K	70K	75K	80K	85K	90K	95K	100K	105K	110K	115K	120K	125K	130K	135K	140K	145K	150K	155K	160K					
LABOUR / MATERIALS																																				
ENGINE OIL	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R			
OIL FILTER	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R			
SPARK PLUGS											R												R													
AIR FILTER			C/C				C/C				R				C/C									R									C/C			
FUEL FILTER							R								R									R									R			
ENGINE TUNING																																				
ENGINE COOLANT	I		I		I		I/R		I		I		I		I/R		I		I		I		I		I		I		I		I		I			
DRIVE BELT	I		I		I		I		I		I		I		I		I		I		I		I		I		I		I		I		I			
ENGINE IDLE SPEED			I				I				I				I				I				I				I				I			I		
COOLING SYSTEM	I		I		I		I		I		I		I		I		I		I		I		I		I		I		I		I		I			
EVAPORATIVE SYSTEM			I				I				I				I				I				I				I				I			I		
BRAKES																																				
BRAKE FLUID	I		I		I		R		I		I		I		R		I		I		I		I		R		I		I		I		R			
PARKING BRAKE	I		I		I		I		I		I		I		I		I		I		I		I		I		I		I		I		I			
DISC BRAKE	I		I		I		I		I		I		I		I		I		I		I		I		I		I		I		I		I			
BRAKE LINES HOSES & CONNECTION			I				I				I				I				I				I				I				I			I		
POWER BRAKE UNIT (BRAKE BOOSTER) & HOSE			I				I				I				I				I				I				I				I			I		
TYRES																																				
ROTATION inc. BALANCING	P		P		P		P		P		P		P		P		P		P		P		P		P		P		P		P		P			
PRESSURE check inc. spare tyre	C/F		C/F		C/F		C/F		C/F		C/F		C/F		C/F		C/F		C/F		C/F		C/F		C/F		C/F		C/F		C/F		C/F			
STEERING ALIGNMENT																																				
STEERING LINKAGES & OPERATIONS			I				I				I				I				I				I				I				I			I		
CHASSIS																																				
FRT & RR SUSPENSION, BALL JOINTS							I								I																			I		
FUEL LINES & HOSES							I								I																				I	
DRIVE SHAFT BOOT							I								I																				I	
EXHAUST SYSTEM HEAT SHIELD							I								I																				I	
BOLTS & NUTS ON CHASSIS & BODY			T				T								T																				T	
MANUAL TRANSMISSION OIL																																				
REAR DIFFERENTIAL OIL																																				R
ELECTRICAL																																				
BATTERY CONDITION	I		I		I		I		I		I		I		I		I		I		I		I		I		I		I		I		I			
ELECTRICAL SYSTEM & LIGHTING	I		I		I		I		I		I		I		I		I		I		I		I		I		I		I		I		I		I	
AIR -CON																																				
CABIN FILTER			R				R								R																				R	
	R		C/F				I								L																				I/A	
	REPLACE		CHECK /FILL UP				INSPECTION								LUBRICATE																				INSPECT/ADJUST	
FREE CAR WASH & VACUUM																																				